

# Instructions

**95-8554**

IR Flame Detector  
X9800



# Table of Contents

DESCRIPTION . . . . .	1	TROUBLESHOOTING . . . . .	14
Outputs . . . . .	1		
LED . . . . .	2	MAINTENANCE . . . . .	15
Optical Integrity ( <b>oi</b> ) . . . . .	2	Cleaning Procedure . . . . .	15
Communication . . . . .	3	<b>oi</b> Plate Removal. . . . .	15
Data Logging / Event Monitoring . . . . .	3	Periodic Checkout Procedure . . . . .	15
Integral Wiring Compartment. . . . .	3	Clock Battery . . . . .	15
 SIGNAL PROCESSING OPTIONS . . . . .	3	 FEATURES. . . . .	16
 GENERAL APPLICATION INFORMATION . . . . .	4	 SPECIFICATIONS . . . . .	16
Response Characteristics . . . . .	4	 REPLACEMENT PARTS . . . . .	19
Welding . . . . .	4	 DEVICE REPAIR AND RETURN . . . . .	19
Artificial Lighting. . . . .	4	 ORDERING INFORMATION . . . . .	19
EMI / RFI Interference . . . . .	4	Accessories . . . . .	19
Non-Carbon Fires . . . . .	4		
False Alarm Sources . . . . .	4		
Factors Inhibiting Detector Response . . . . .	5		
 IMPORTANT SAFETY NOTES . . . . .	5	APPENDIX A – FM APPROVAL AND PERFORMANCE REPORT . . . . .	21
 INSTALLATION . . . . .	6	APPENDIX B – CSA CERTIFICATION . . . . .	24
Detector Positioning. . . . .	6	APPENDIX C – ATEX APPROVAL . . . . .	25
Detector Orientation. . . . .	6	APPENDIX D – IECEX APPROVAL . . . . .	26
Protection Against Moisture Damage . . . . .	6	APPENDIX E – VdS APPROVAL . . . . .	27
Wiring Procedure . . . . .	7		
EOL Resistors . . . . .	8		
Setting Device Network Addresses (EQP Models Only) . . . . .	13		
 STARTUP PROCEDURE . . . . .	14		
Fire Alarm Test. . . . .	14		



## IR Flame Detector X9800

### **IMPORTANT**

*Be sure to read and understand the entire instruction manual before installing or operating the flame detection system. Any deviation from the recommendations in this manual may impair system performance and compromise safety.*

### **ATTENTION**

*The X9800 includes the Automatic Optical Integrity (oi®) feature — a calibrated performance test that is automatically performed once per minute to verify complete detector operation capabilities. **No testing with an external test lamp is required.***

## **DESCRIPTION**

The evolution continues with the new X9800 IR Flame Detector. The X9800 meets the most stringent requirements worldwide with advanced detection capabilities and immunity to extraneous sources, combined with a superior mechanical design. The detector is equipped with both automatic and manual oi test capability. The detector has Division and Zone explosion-proof ratings and is suitable for use in indoor and outdoor applications.

The standard output configuration includes fire, fault and auxiliary relays. Output options include:

- 0 to 20 mA output (in addition to the three relays)
- Pulse output for compatibility with existing controller based systems (with fire and fault relays)
- Eagle Quantum Premier (EQP) compatible model (no analog or relay outputs)
- HART Communication



A multi-color LED on the detector faceplate indicates detector status condition.

Microprocessor controlled heated optics increase resistance to moisture and ice.

The X9800 housing is available in copper-free aluminum or stainless steel, both with NEMA 4X and IP66 rating.

## **OUTPUTS**

### **Relays**

The standard detector is furnished with fire, fault and auxiliary relays. All three relays are rated 5 amperes at 30 Vdc.

The Fire Alarm relay has redundant terminals and normally open / normally closed contacts, normally de-energized operation, and latching or non-latching operation.

The Fault relay has redundant terminals and normally open contacts, normally energized operation, and latching or non-latching operation.

The Auxiliary relay has normally open / normally closed contacts, and is configurable for energized or de-energized operation, and latching or non-latching operation.

### 0 to 20 mA Output

A 0 to 20 mA output is available as an option (in addition to the three relays). This option provides a 0 to 20 mA dc current output for transmitting detector status information to other devices. The circuit can be wired in either an isolated or non-isolated configuration and can drive a maximum loop resistance of 500 ohms from 18 to 19.9 Vdc and 600 ohms from 20 to 30 Vdc. Table 1 indicates the detector status conditions represented by the various current levels. The output is calibrated at the factory, with no need for field calibration. A model with relays and 0-20 mA with HART is also available. Refer to Addendum number 95-8637 for complete details.

#### NOTE

*The output of the 0 to 20 mA current loop is not monitored by the fault detection circuitry of the X9800. Therefore, an open circuit on the loop will not cause the fault relay to change state or the detector status LED to indicate a fault. The status of the LED always follows the status of the relays.*

An alarm condition will normally over-ride a fault condition, unless the nature of the fault condition impairs the ability of the detector to generate or maintain an alarm output, i.e. loss of operating power.

Table 1—Detector Status Conditions Indicated by Current Level

Current Level (±0.3 mA)	Detector Status
0 mA	Power Fault
1 mA	General Fault
2 mA	<b>oi</b> Fault
4 mA	Normal Operation
16 mA	Pre-Alarm
20 mA	Fire Alarm

### LON/SLC Output

The EQP model is designed for use exclusively with the Det-Tronics Eagle Quantum Premier system. The detector communicates with the system controller over a digital communication network or LON/SLC (Local Operating Network / Signalling Line Circuit). The LON/SLC is a fault tolerant, two wire digital communication network arranged in a loop configuration. Analog and relay outputs are not available on this model.

Table 2—Detector Status Indicator

Detector Status	LED Indicator
Power On/Normal Auto <b>oi</b> (no fault or fire alarm)	Green
Power On/Normal Man <b>oi</b>	Green, flashing on for 0.5 sec. every 5 sec.
Fault	Yellow
Pre-Alarm/Background IR	Red, flashing on for 500 ms. and off for 500 ms.
Fire (Alarm)	Steady Red
On Power-Up, The LED Flashes in Sequence as Follows, Indicating Sensitivity and Signal Processing Status	
Low IR Sensitivity	One Green Flash
Medium IR Sensitivity	Two Green Flashes
High IR Sensitivity	Three Green Flashes
Very High IR Sensitivity	Four Green Flashes
Quick Fire/TDSA IR Signal	One Yellow Flash
TDSA only IR Signal	Two Yellow Flashes

### LED

A tricolor LED on the detector faceplate indicates normal, fire alarm and fault conditions. Table 2 indicates the condition of the LED for each status.

### OPTICAL INTEGRITY (**oi**)

#### Automatic **oi**

The X9800 includes the Automatic Optical Integrity (**oi**) feature — a calibrated performance test that is automatically performed once per minute to verify complete detector operation capabilities. No testing with an external test lamp is required. The detector automatically performs the same test that a maintenance person with a test lamp would perform — once every minute, 60 times per hour. However, a successful automatic **oi** test does not produce an alarm condition.

The X9800 signals a fault condition when less than half of the detection range remains. This is indicated by the Fault relay and is evident by the yellow color of the LED on the face of the detector. See the "Troubleshooting" section for further information.

#### Magnetic **oi** / Manual **oi**

The detector also incorporates both magnetic **oi** and manual **oi** features that provide the same calibrated test as the automatic **oi**, and in addition actuates the Alarm relay to verify output operation for preventive maintenance requirements. These features can be performed at any time and eliminate the need for testing with a non-calibrated external test lamp.

### CAUTION

*These tests require disabling of all extinguishing devices to avoid release resulting from a successful test.*

The magnetic **oi** test is performed by placing a magnet by the marked location (mag **oi**) on the outside of the detector. The manual **oi** test is accomplished by connecting the **oi** lead (terminal 22) to power supply minus via an external switch. The magnet or switch must be held in place for a minimum of 6 seconds to complete the test. Either of these test methods activates the calibrated IR emitter. If the resulting signal meets the test criteria, indicating that greater than half of the detection range remains, the Alarm relay changes state, the indicating LED changes to red, and the 0-20 mA current output goes to 20 mA. This condition remains until the magnet is removed or the switch is released, regardless of whether the relays are set for latching or non-latching operation.

If less than half of the detection range remains, no alarm is produced and a fault is generated. The fault indication can be reset by momentarily applying the magnet or manual **oi** switch.

### NOTE

*Refer to the Appendix A for FM verification of Det-Tronics' Optical Integrity **oi** function.*

### COMMUNICATION

The X9800 is furnished with an RS-485 interface for communicating status and other information with external devices. The RS-485 uses MODBUS protocol, with the detector configured as a slave device.

### NOTE

*The EQP model uses LON/SLC communication. RS-485 communication is not available on the EQP model.*

### DATA LOGGING / EVENT MONITORING

Data logging for event monitoring capability is also provided. The detector can log up to 1500 events (up to 1000 general and 500 alarm events). Status conditions such as normal, power down, general and **oi** faults, pre-alarm, fire alarm, time and temperature are recorded. Each event is time and date stamped, along with the temperature and input voltage. Event data is stored in non-volatile memory when the event becomes active, and again when the status changes. Data is accessible using the RS-485 port or the EQP controller.

### INTEGRAL WIRING COMPARTMENT

All external wiring to the device is connected within the integral junction box. The screw terminals accept wiring from 14 to 24 AWG. The detector is furnished with four conduit entries, with either 3/4 inch NPT or 25 mm threads.

### SIGNAL PROCESSING OPTIONS

The X9800 features signal processing options. These options determine the type of logic that the detector will use for processing fire signals to customize the X9800 to the application. Two signal processing options are available for the X9800:

- TDSA enabled
- Both TDSA and Quick Fire enabled (either initiates fire alarm).

### Time Domain Signal Analysis (TDSA)

The TDSA signal processing technique analyzes the input signal in real time, requiring the IR signal to flicker randomly in order to recognize it as a fire condition.

Using TDSA signal processing, the X9800 ignores regularly chopped blackbody sources (occurring in areas where moving conveyors and hot objects in proximity to one another result in a regularly chopped IR signal), because it looks for a less uniform signal. However, in the presence of a regularly chopped signal, the unit is more susceptible to false alarms due to sporadic IR that functions as a trigger when occurring in conjunction with the regularly chopped signal.

### Quick Fire (High Speed)

The Quick Fire (High Speed) feature can be used in conjunction with the TDSA signal processing method. This method overrides TDSA requirements in the event of an intense signal. When Quick Fire is activated, the detector is capable of responding to an intense fire signal in less than 30 milliseconds (0.030 seconds). Using the Quick Fire feature in conjunction with TDSA signal processing allows the detector to provide a high speed response to a large, non-flickering fire (such as in high pressure gas applications) while maintaining an ability to respond to smaller fires.

## **GENERAL APPLICATION INFORMATION**

### **RESPONSE CHARACTERISTICS**

Response is dependent on distance, type of fuel, temperature of the fuel, and time required for the fire to come to equilibrium. As with all fire tests, results must be interpreted according to an individual application.

See Appendix A for fire test results.

### **WELDING**

It is recommended that the system be bypassed during welding operations in situations where the possibility of a false alarm cannot be tolerated. Gas welding mandates system bypass, since the gas torch is an actual fire. Arc welding rods can contain organic binder materials in the flux that burn during the welding operation and are detectable by the X9800. Welding rods with clay binders do not burn and will not be detected by the X9800. However, system bypass is always recommended, since the material being welded may be contaminated with organic substances (paint, oil, etc.) that will burn and possibly trigger the X9800.

### **ARTIFICIAL LIGHTING**

The X9800 should not be located within 3 feet of artificial lights. Excess heating of the detector could occur due to heat radiating from the lights.

### **EMI/RFI INTERFERENCE**

The X9800 is resistant to interference by EMI and RFI, and is EMC Directive compliant and CE marked. It will not respond to a 5 watt walkie-talkie at distances greater than 1 foot.

### **NON-CARBON FIRES**

The response of the X9800 is limited to carbonaceous fuels. It should not be used to detect fires from fuels that do not contain carbon, such as hydrogen, sulfur and burning metals.

## **FALSE ALARM SOURCES**

The detector has been designed to ignore steady state infrared sources that do not have a flicker frequency characteristic of a fire, however, it should be noted that if these steady state infrared sources are hot enough to emit adequate amounts of infrared radiation in the response range of the IR sensor and if this radiation becomes interrupted from the view of the detector in a pattern characteristic of a flickering flame, the IR sensor can respond.

Any object having a temperature greater than 0° Kelvin (-273°C) emits infrared radiation. The hotter the object, the greater the intensity of the emitted radiation. The closer the infrared source is to the detector, the greater the potential for a false alarm. The IR sensor can respond to IR radiation sources that can meet the amplitude and flicker requirements of the detector such as vibrating hot objects.

## FACTORS INHIBITING DETECTOR RESPONSE

### Windows

Glass and Plexiglas windows significantly attenuate radiation and must not be located between the detector and a potential flame source. If the window cannot be eliminated or the detector location changed, contact Detector Electronics for recommendations regarding window materials that will not attenuate radiation.

### Obstructions

Radiation must be able to reach the detector in order for it to respond. Care must be taken to keep physical obstructions out of the line of view of the detector.

### Smoke

Smoke will absorb radiation. If accumulations of dense smoke can be expected to precede the presence of a flame, then detectors that are used in enclosed areas should be mounted on the wall approximately 3 feet (1 meter) from the ceiling where the accumulation of smoke is reduced.

### Detector Viewing Windows

It is important to keep the detector viewing windows as free of contaminants as possible in order to maintain maximum sensitivity. Commonly encountered substances that can significantly attenuate IR radiation include, but are certainly not limited to, the following:

Dust and dirt buildup  
Paint overspray  
Water and ice.

## IMPORTANT SAFETY NOTES

### WARNING

*Do not open the detector assembly in a hazardous area when power is applied. The detector contains limited serviceable components and should never be opened. Doing so could disturb critical optical alignment and calibration parameters, possibly causing serious damage. This type of damage could be undetected and could result in failure to see a fire and/or false alarm.*

### CAUTION

*The wiring procedures in this manual are intended to ensure proper functioning of the device under normal conditions. However, because of the many variations in wiring codes and regulations, total compliance to these ordinances cannot be guaranteed. Be certain that all wiring complies with the NEC as well as all local ordinances. If in doubt, consult the authority having jurisdiction before wiring the system. Installation must be done by a properly trained person.*

### CAUTION

*To prevent unwanted actuation or alarm, extinguishing devices must be disabled prior to performing detection system tests or maintenance.*

### CAUTION

*The IR flame detectors are to be installed in places where the risk of mechanical damages is low.*

### ATTENTION

*Remove the protective cap from the front of the detector before activating the system.*

### ATTENTION

*Observe precautions for handling electrostatic sensitive devices.*

## INSTALLATION

### NOTE

The recommended lubricant for threads and O-rings is a silicone free grease (part number 005003-001) available from Detector Electronics. Under no circumstances should a lubricant containing silicone be used.


### DETECTOR POSITIONING

Detectors should be positioned to provide the best unobstructed view of the area to be protected. The following factors should also be taken into consideration:

- Identify all high risk fire ignition sources.
- Be sure that enough detectors are used to adequately cover the hazardous area.
- Be sure that the unit is easily accessible for cleaning and other periodic servicing.
- Locate and position the detector so that the fire hazard(s) are within both the field of view and detection range of the device. Refer to Appendix A for specific information.
- The detector should be aimed downward at least 10 to 20 degrees to allow lens openings to drain. See Figure 1. **The detector should be positioned so that its field of view does not cover areas outside the hazardous area.** This will minimize the possibility of false alarms caused by activities outside the area requiring protection.
- For best performance, the detector should be mounted on a rigid surface in a low vibration area.
- Dense fog, rain as well as certain gases and vapors can absorb IR radiation and reduce the sensitivity of the detector.
- Verify that all detectors in the system are properly aimed at the area to be protected. (The Det-Tronics Q1201C Laser Aimer is recommended for this purpose.)
- If possible, fire tests should be conducted to verify correct detector positioning and coverage.
- For ATEX installations, the X9800 detector housing must be electrically connected to earth ground.

### DETECTOR ORIENTATION

Refer to Figure 2 and ensure that the **oi** plate will be oriented as shown when the X9800 is mounted and sighted. This will ensure proper operation of the **oi** system and will also minimize the accumulation of moisture and contaminants between the **oi** plate and the viewing windows.



NOTE: DETECTOR MUST ALWAYS BE AIMED DOWNWARD AT LEAST 10 TO 20 DEGREES.

Figure 1—Detector Orientation Relative to Horizon

### IMPORTANT

The **oi** plate **must** be securely tightened to ensure proper operation of the **oi** system (40 oz./inches recommended).

### PROTECTION AGAINST MOISTURE DAMAGE

It is important to take proper precautions during installation to ensure that moisture will not come in contact with the electrical connections of the system. The integrity of the system regarding moisture protection must be maintained for proper operation and is the responsibility of the installer.




Figure 2—Front View of the X9800



If conduit is used, we recommend installing drains, according to local codes, at water collection points to automatically drain accumulated moisture. It is also recommended to install at least one breather, according to local codes, at upper locations to provide ventilation and allow water vapor to escape.

Conduit raceways should be inclined so that water will flow to low points for drainage and will not collect inside enclosures or on conduit seals. If this is not possible, install conduit drains above the seals to prevent the collection of water or install a drain loop below the detector with a conduit drain at the lowest point of the loop.

Conduit seals are not required for compliance with explosion-proof installation requirements, but are highly recommended to prevent water ingress in outdoor applications. Units with M25 thread must use an IP66 washer or an O-ring sealed adapter/gland to prevent water ingress.

## WIRING PROCEDURE

### Wire Size and Type

The system should be wired according to local codes. The wire size selected should be based on the number of detectors connected, the supply voltage and the cable length. Typically 14 AWG (2.08 mm<sup>2</sup>) or 16 AWG (1.31 mm<sup>2</sup>) shielded cable is recommended. Wires should be stripped 3/8 inch (9 mm). A minimum input voltage of 18 Vdc must be present at the X9800.





Figure 3—Q9033 Mounting Bracket Dimensions in Inches (cm)  
(See Figure 1 for Correct Detector Orientation.)

## NOTE

*Refer to "Power Consumption" in the "Specifications" section of this manual.*

The use of shielded cable is required to protect against interference caused by EMI and RFI. When using cables with shields, terminate the shields as shown in Figures 7 through 12, and Figure 14. Consult the factory if not using shielded cable.

In applications where the wiring cable is installed in conduit, the conduit must not be used for wiring to other electrical equipment.

If disconnection of power is required, separate disconnect capability must be provided.

## CAUTION

*Installation of the detector and wiring should be performed only by qualified personnel.*

## Detector Mounting

Install the swivel mounting bracket assembly on the wall. The installation surface should be free of vibration and suitable to receive 1/4 inch (M6) screws with a length of at least 1 inch (25 mm), and have sufficient capacity to hold the detector and bracket weight. Refer to Figure 3 for dimensions.

## Relay and 0-20 mA Output Models

Follow the instructions below to install the X9800.

1. Make field connections following local ordinances and guidelines in this manual. Refer to Figures 4 through 12.
2. Check all field wiring to be sure that the proper connections have been made.

### IMPORTANT

*Do not test any wiring connected to the detector with a meg-ohmmeter. Disconnect wiring at the detector before checking system wiring for continuity.*

3. Make the final sighting adjustments and ensure that the mounting bracket hardware is tight.



Figure 4—X9800 Terminal Block

9	4-20 mA +	19	4-20 mA –	SPARE	29
8	4-20 mA + REF	18	4-20 mA – REF	SPARE	28
7	COM FIRE	17	COM FIRE	COM AUX	27
6	N.O. FIRE	16	N.O. FIRE	N.O. AUX	26
5	N.C. FIRE	15	N.C. FIRE	N.C. AUX	25
4	COM FAULT	14	COM FAULT	RS-485 A	24
3	N.O. FAULT	13	N.O. FAULT	RS-485 B	23
2	24 VDC +	12	24 VDC +	MAN O <sub>i</sub>	22
1	24 VDC –	11	24 VDC –	24 VDC –	21

B2061

Figure 5—Wiring Terminal Identification

## EOL RESISTORS (Not Used with EQP Model)

To ensure that the insulating material of the wiring terminal block will not be affected by the heat generated by EOL resistors, observe the following guidelines when installing the resistors.

1. Required EOL resistor power rating must be 5 watts minimum.


### NOTE

*EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts. **This applies to ATEX/IEC installations only.***

2. Resistor leads should be cut to a length of approximately 1 1/2 inches (40 mm).
3. Bend the leads and install the EOL resistor as shown in Figure 6.
4. Maintain a 3/8 inch (10 mm) minimum gap between the resistor body and the terminal block or any other neighboring parts.

### NOTE

*The EOL resistor can only be used within the flameproof terminal compartment. Unused apertures shall be closed with suitable blanking elements.*



A2126

Figure 6—EOL Resistor Installation




Figure 7—Ex d Wiring Option




Figure 8—Ex e Wiring Option




Figure 9—X9800 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sourcing)




Figure 10—X9800 Detector Wired for Non-Isolated 0 to 20 mA Current Output (Sinking)




Figure 11—X9800 Detector Wired for Isolated 0 to 20 mA Current Output (Sourcing)




Figure 12—X9800 Detector Wired for Isolated 0 to 20 mA Current Output (Sinking)

**NOTES: 1. INDIVIDUAL MANUAL or TEST SWITCHES CAN BE INSTALLED REMOTELY OR A DETECTOR SELECTOR AND ACTIVATION SWITCH CAN BE INSTALLED AT THE FIRE PANEL. TEST SWITCHES ARE NOT SUPPLIED.**

## EQP Model

1. Connect external wires to the appropriate terminals inside the device junction box. (See Figure 13 for terminal identification.)
2. Connect the shield of the power cable to “earth ground” at the power source.
3. Connect shields for the LON cable as indicated. See Figure 14.

### NOTE

*DO NOT ground any shields at the detector housing.*

4. Set the device network address. (See “Setting Device Network Addresses” section of this manual for switch setting procedure.)

5. Check all field wiring to be sure that the proper connections have been made.
6. Replace the device cover.
7. Make the final sighting adjustments and ensure that the mounting bracket hardware is tight.

### NOTE

*Refer to the Eagle Quantum Premier system manual (number 95-8533) for information regarding power and network communication cable requirements.*

COM SHIELD	6	16	COM SHIELD
COM 1 A	5	15	COM 2 A
COM 1 B	4	14	COM 2 B
POWER SHIELD	3	13	POWER SHIELD
24 VDC +	2	12	24 VDC +
24 VDC –	1	11	24 VDC –

A2089

Figure 13—Wiring Terminal Identification for X9800 EQP Model




Figure 14—A Typical EQP System




Figure 15—Location of Address Switches

## SETTING DEVICE NETWORK ADDRESSES (EQP Models Only)

### Overview of Network Addresses

Each device on the LON must be assigned a unique address. Addresses 1 to 4 are reserved for the controller. Valid addresses for field devices are from 5 to 250.

#### IMPORTANT

*If the address is set to zero or an address above 250, the switch setting will be ignored.*

Duplicated addresses are not automatically detected. Modules given the same address will use the number given and report to the controller using that address. The status word will show the latest update, which could be from any of the reporting modules using that address.

### Setting Field Device Addresses

Selection of the node address is done by setting rocker switches on an 8 switch “DIP Switch Assembly” within the detector’s housing. Refer to Figure 15 for switch location.

#### WARNING

*The network address switches are located within the detector housing. Disassembly of the detector head that contains powered electrical circuits is required to gain access to the network address switches. For hazardous areas, the area must be de-classified before attempting disassembly of the device. Always observe precautions for handling electrostatic sensitive devices.*

The address number is binary encoded with each switch having a specific binary value with switch 1 being the LSB (Least Significant Bit). (See Figure 16) The device’s LON address is equal to the added value of all closed rocker switches. All “Open” switches are ignored.

**Example:** for node No. 5, close rocker switches 1 and 3 (binary values 1 + 4); for node No. 25, close rocker switches 1, 4 and 5 (binary values 1 + 8 + 16).

#### NOTE

*The field device sets the LON address only when power is applied to the device. Therefore, it is important to set the switches **before** applying power. If an address is ever changed, system power must be cycled before the new address will take effect.*

After setting address switches, record the address number and device type.




Figure 16—Address Switches for X9800

## STARTUP PROCEDURE

When installation of the equipment is complete, perform the “Fire Alarm Test” below.

Allow 20 to 30 minutes for the detector’s heated optics to reach equilibrium.

### FIRE ALARM TEST

1. Disable any extinguishing equipment that is connected to the system.
2. Apply input power to the system.
3. Initiate an **oi** test. (See “Magnetic **oi** / Manual **oi**” under Optical Integrity in the Description section of this manual.
4. Repeat this test for all detectors in the system. If a unit fails the test, refer to the “Troubleshooting” section.
5. Verify that all detectors in the system are properly aimed at the area to be protected. (The Det-Tronics Q1201C Laser Aimer is recommended for this purpose.)
6. Enable extinguishing equipment when the test is complete.

## TROUBLESHOOTING

### WARNING

*The sensor module (“front” half of the detector) contains no user serviceable components and should never be opened. The terminal compartment is the only part of the enclosure that should be opened by the user in the field.*

1. Disable any extinguishing equipment that is connected to the unit.
2. Inspect the viewing windows for contamination and clean as necessary. (Refer to the “Maintenance” section for complete information regarding cleaning of the detector viewing windows.)
3. Check input power to the unit.
4. If the fire system has a logging function, check the fire panel log for output status information. See Table 3 for information regarding 0 to 20 mA output.

Table 3—Current Level Output Troubleshooting Guide

Current Level (±0.3 mA)	Status	Action
0 mA	Power Fault	Check system wiring.
1 mA	General Fault	Cycle power. <sup>1</sup>
2 mA	<b>oi</b> Fault	Clean windows. <sup>2</sup>
4 mA	Normal Operation	
16 mA	Hi Background IR	Remove IR source or aim detector away from IR source.
20 mA	Fire Alarm	

<sup>1</sup>If fault continues, return device to factory for repair.

<sup>2</sup>See “Maintenance” section for cleaning procedure.

5. Turn off the input power to the detector and check all wiring for continuity. **Important: Disconnect wiring at the detector before checking system wiring for continuity.**
6. If all wiring checks out and cleaning of the **oi** plate/window did not correct the fault condition, check for high levels of background IR radiation by covering the detector with the factory supplied cover or aluminum foil. If the fault condition clears, extreme background IR radiation is present. Re-adjust the view of the detector away from the IR source or relocate the detector.

If none of these actions corrects the problem, return the detector to the factory for repair.

### NOTE

*It is highly recommended that a complete spare be kept on hand for field replacement to ensure continuous protection.*



## MAINTENANCE

### IMPORTANT

*Periodic flamepath inspections are not recommended, since the product is not intended to be serviced and provides proper ingress protection to eliminate potential deterioration of the flamepaths.*

### WARNING

*The sensor module ("front" half of the detector) contains no user serviceable components and should never be opened. The terminal compartment is the only part of the enclosure that should be opened by the user in the field.*

To maintain maximum sensitivity and false alarm resistance, the viewing windows of the X9800 must be kept relatively clean. Refer to the procedure below for cleaning instructions.

## CLEANING PROCEDURE

### CAUTION

*Disable any extinguishing equipment that is connected to the unit to prevent unwanted actuation.*

To clean the windows and **oi** plate, use Det-Tronics window cleaner (part number 001680-001) and a soft cloth, cotton swab or tissue and refer to the following procedure.

1. **Disable any extinguishing equipment that is connected to the unit.**

### NOTE

*Remove input power when cleaning the detector windows. The rubbing motion on the surface of the windows during cleaning can create static electricity that could result in unwanted output activation.*

2. To clean the optical surfaces, remove the **oi** plate following the procedure described below.
3. Thoroughly clean both viewing windows and reflective surfaces of the **oi** plate using a clean cloth, cotton swab or tissue, and Det-Tronics window cleaning solution. If a stronger solution is needed, isopropyl alcohol may be used.
4. Re-install the **oi** plate following the procedure described below.

## oi PLATE REMOVAL

1. **Disable any extinguishing equipment that is connected to the unit.**
2. Loosen the two captive screws, then grasp the **oi** plate by the visor and remove it from the detector. See Figure 17.
3. Thoroughly clean the **oi** plate reflective surfaces, holding it by its edges to avoid leaving fingerprints on the inside reflective surface.
4. Re-install the **oi** plate. Ensure that the plate is flat on the detector surface. Tighten the **oi** plate screws securely (40 oz/inches).

### NOTE

*If the **oi** plate is removed, be sure to install the original **oi** plate. **Oi** plates are not interchangeable and should not be mixed with **oi** plates from other detectors. If corrosive contaminants in the atmosphere cause the **oi** plate surface to deteriorate to the extent that it is no longer possible to restore it to its original condition, it must be replaced. Consult factory for **oi** plate replacement procedure.*

## PERIODIC CHECKOUT PROCEDURE

A checkout of the system using the manual or magnetic **oi** feature should be performed on a regularly scheduled basis to ensure that the system is operating properly. To test the system, perform the "Fire Alarm Test" as described in the "Startup Procedure" section of this manual.

## CLOCK BATTERY (Not used with EQP Model)

The real time clock has a backup battery that will operate the clock with no external power for nominally 10 years. It is recommended that the battery be replaced every 7 years. Return the device to the factory for battery replacement.

### NOTE

*If the backup battery is depleted, there is no effect on the operation of the flame detector, but the time stamping of the data log may be affected.*



Figure 17—**oi** Plate Removal

## FEATURES

- Responds to a fire in the presence of modulated blackbody radiation (i.e. heaters, ovens, turbines) without false alarm.
- High speed capability — 30 milliseconds.
- Built-in data logging / event monitoring, up to 1500 events (up to 1000 general, 500 alarms).
- Microprocessor controlled heated optics for increased resistance to moisture and ice.
- Automatic, manual or magnetic optical integrity (oi) testing.
- Easily replaceable oi plate.
- Fire, fault and auxiliary relays standard.
- 0 to 20 mA isolated output (optional).
- Eagle Quantum Premier LON/SLC output (optional).
- Tricolor LED indicates normal operation, fire and fault conditions.
- Operates under adverse weather conditions.
- Mounting swivel allows easy sighting.
- Integral wiring compartment for ease of installation.
- Explosion-proof/flame-proof detector housing. Meets FM, CSA, ATEX and CE certification requirements.
- Class A wiring per NFPA-72.
- Meets NFPA-33 response requirement for under 0.5 second (available when model selected).
- 3 year warranty.
- Advanced signal processing (TDSA).
- RFI and EMC Directive compliant.

## ASSOCIATED MANUALS

List of X9800 related manuals:

TITLE	FORM NUMBER
Pulse	95-8555
EQP	95-8533
HART Addendum	95-8637

## SPECIFICATIONS

### OPERATING VOLTAGE—

24 Vdc nominal (18 Vdc minimum, 30 Vdc maximum).  
Maximum ripple is 2 volts peak-to-peak.

### POWER CONSUMPTION—

Without heater: 2.1 watts at 24 Vdc nominal;  
3.5 watts at 24 Vdc in alarm.  
2.2 watts at 30 Vdc nominal;  
4.0 watts at 30 Vdc in alarm.

Heater only: 8 watts maximum.

Total power: 16.5 watts at 30 Vdc with EOL resistor installed and heater on maximum.

EOL resistor must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

For HART model, refer to Addendum number 95-8637.

### POWER UP TIME—

Fault indication clears after 0.5 second; device is ready to indicate an alarm condition after 30 seconds.

### OUTPUT RELAYS—

Fire Alarm relay, Form C, 5 amperes at 30 Vdc:

The Fire Alarm relay has redundant terminals and normally open / normally closed contacts, normally de-energized operation, and latching or non-latching operation.

Fault relay, Form A, 5 amperes at 30 Vdc:

The Fault relay has redundant terminals and normally open contacts, normally energized operation, and latching or non-latching operation.

Auxiliary relay, Form C, 5 amperes at 30 Vdc:

The auxiliary relay has normally open / normally closed contacts, normally energized or de-energized operation, and latching or non-latching operation.

### CURRENT OUTPUT (Optional)—

0 to 20 milliampere ( $\pm 0.3$  mA) dc current, with a maximum loop resistance of 500 ohms from 18 to 19.9 Vdc and 600 ohms from 20 to 30 Vdc.

### LON OUTPUT—

Digital communication, transformer isolated (78.5 kbps).

### TEMPERATURE RANGE—

Operating:  $-40^{\circ}\text{F}$  to  $+167^{\circ}\text{F}$  ( $-40^{\circ}\text{C}$  to  $+75^{\circ}\text{C}$ ).

Storage:  $-67^{\circ}\text{F}$  to  $+185^{\circ}\text{F}$  ( $-55^{\circ}\text{C}$  to  $+85^{\circ}\text{C}$ ).

Hazardous location ratings from  $-55^{\circ}\text{C}$  to  $+75^{\circ}\text{C}$  available on flameproof model.

### HUMIDITY RANGE—

0 to 95% relative humidity, can withstand 100% condensing humidity for short periods of time.

100% REPRESENTS THE MAXIMUM DETECTION DISTANCE FOR A GIVEN FIRE. THE SENSITIVITY INCREASES AS THE ANGLE OF INCIDENCE DECREASES.




Figure 18—Detector Cone of Vision

#### CONE OF VISION—

The detector has a 90° cone of vision (horizontal) with the highest sensitivity lying along the central axis. See Figure 18.

#### RESPONSE TIME—

32 inch methane plume: < 10 seconds.  
1 foot x 1 foot n-Heptane: < 15 seconds.  
(See Appendix A for details.)

#### ENCLOSURE MATERIAL—

Copper-free aluminum (painted) or 316 stainless steel.

#### VIBRATION—

Conformance per FM 3260: 2000, MIL-STD 810C (Curve AW).

#### DIMENSIONS—

See Figure 19.

#### WIRING—

Field wiring screw terminals are UL/CSA rated for up to 14 AWG wire, and are DIN/VDE rated for 2.5 mm<sup>2</sup> wire. Screw terminal required torque range is 3.5–4.4 in.-lbs. (0.4–0.5 N·m).

14 AWG (2.08 mm<sup>2</sup>) or 16 AWG (1.31 mm<sup>2</sup>) shielded cable is recommended.

**Important:** 18 Vdc minimum must be available at the detector. For ambient temperatures below –10°C and above +60°C use field wiring suitable for both minimum and maximum ambient temperature.

#### THREAD SIZE—

Conduit connection: Four entries, 3/4 inch NPT or M25.  
Conduit seal not required.

#### SHIPPING WEIGHT (Approximate)—

Aluminum: 6 pounds (2.75 kilograms).

Stainless Steel: 10 pounds (4.5 kilograms).

Swivel Mount (AL): 6 pounds (2.75 kilograms).

Swivel Mount (SS): 14 pounds (6.4 kilograms).

#### WARRANTY PERIOD—

**3 years.**




Figure 19—Dimensions in Inches (cm)

## CERTIFICATION—



For complete FM certification details, refer to Appendix A.

For complete CSA certification details, refer to Appendix B.



For complete ATEX certification details, refer to Appendix C.

## IECEX

For complete IECEx certification details, refer to Appendix D.

## VdS

Performance per EN54-10,  
Certificate of Approval G-203084.

EC-Certificate of Conformity  
08 0786 – CPD – 20779  
EN54-10 Flame detectors - Point detectors.

For complete VdS certification details, refer to Appendix E.

### NOTE

*Operational performance verified from -40°C to +75°C.*

### NOTE

*An optional third party addressable module can only be used within the Ex d flameproof model unless the addressable module is component certified as Ex e for use within the Ex d e increased safety model.*

### NOTE

*Refer to “EOL Resistors” section for installation details. All cable entry devices and blanking elements shall be certified to “E-generation” or “ATEX” standards, in type of explosion protection increased safety “e” or flameproof enclosure “d” (as applicable), suitable for the conditions of use and correctly installed. They shall maintain the degree of ingress protection IP66 for the apparatus. Unused apertures shall be closed with suitable blanking elements.*

### NOTE

*For ATEX installations, the X9800 detector housing must be electrically connected to earth ground.*

## REPLACEMENT PARTS

The detector is not designed to be repaired in the field. If a problem should develop, refer to the Troubleshooting section. If it is determined that the problem is caused by an electronic defect, the device must be returned to the factory for repair.

## DEVICE REPAIR AND RETURN

Prior to returning devices, contact the nearest local Detector Electronics office so that a Return Material Identification (RMI) number can be assigned. **A written statement describing the malfunction must accompany the returned device or component to assist and expedite finding the root cause of the failure.**

Pack the unit properly. Always use sufficient packing material. Where applicable, use an antistatic bag as protection from electrostatic discharge.

### NOTE

*Inadequate packaging that ultimately causes damage to the returned device during shipment will result in a service charge to repair the damage incurred during shipment.*

Return all equipment transportation prepaid to the factory in Minneapolis.

### NOTE

*It is highly recommended that a complete spare be kept on hand for field replacement to ensure continuous protection.*

## ORDERING INFORMATION

When ordering, please specify:

X9800 IR Flame Detector

Refer to the X9800 Model Matrix below for details

Q9033 mount is required:

Q9033A for aluminum detectors only.

Q9033B for aluminum and stainless steel detectors.

## X-SERIES FLAME DETECTOR ACCESSORIES

Part Number	Description
000511-029	Converter RS485 to RS232
001680-001	Window cleaner (6 pack)
005003-001	1 oz grease for detectors (non-silicon)
006097-001	Q1201 Laser
007240-001	Q1116A1001, Air Shield (AL)
007255-001	Q1201C1001 X-Series Laser Holder (AL/Plastic)
007290-001	Q9033B Stainless Steel Swivel Mount Assembly is for aluminum and stainless steel detectors
007290-002	Q9033A Aluminum Swivel Mount Assembly is for aluminum detectors only
007307-001	<b>oi</b> plate for X3301 (requires inspector connector to calibrate)
007307-002	<b>oi</b> plate for X52/X22/X98 (requires inspector connector to calibrate)
007307-003	<b>oi</b> plate for X3302 (requires inspector connector to calibrate)
007338-001	Q2000A1001 X-Series Weather Shield (AL)
007338-010	Q2033A10R X3301/X3302 FOV Limiter 10° (AL)
007338-020	Q2033A20R X3301/X3302 FOV Limiter 20° (AL)
007338-030	Q2033A30R X3301/X3302 FOV Limiter 30° (AL)
007739-001	Magnet and Extension Pole
007818-001	Q1118A1001 Aluminum Air Shield/Flange Mount (AL)
007818-002	Q1118S1001 Stainless Steel Air Shield/Flange Mount (SS)
007819-001	W6300B1002 Inspector Connector (Inspector Monitor software included)
007912-010	Spare Restrictor Plate 10° (AL)
007912-020	Spare Restrictor Plate 20° (AL)
007912-030	Spare Restrictor Plate 30° (AL)
009177-001	Q1120A1001 Paint shield mounting ring (AL)
009199-001	Q1198A1001 Dual Air Shield/Flange Mount (X9800 only)/(AL)
009207-001	Inspector Monitor CD
009208-001	<b>oi</b> kit (5 plates) with Inspector Connector and Monitor X3301
009208-002	<b>oi</b> kit (5 plates) with Inspector Connector and Monitor X52/X22/X98
101197-003	Stop Plug, SS, IP66, Ex d e, M25 (SS)
102740-002	Magnet
102871-001	Laser Battery, 3V Lithium (laser)
103922-001	Model 475 HART Communicator
103363-001	14mm Hex Wrench (Steel)
103406-001	Screwdriver
103517-001	Stop Plug, AL, IP66, Ex d e, M25 (AL)
107427-040	O-ring - Rear Cover (Viton)

## X9800 MODEL MATRIX

MODEL	DESCRIPTION		
X9800	Single Frequency IR Flame Detector		
	TYPE	MATERIAL	
	A	Aluminum	
	S	Stainless Steel (316)	
	TYPE	THREAD TYPE	
	4M	4 PORT, METRIC M25	
	4N	4 PORT, 3/4" NPT	
	TYPE	OUTPUTS	
	11	Relay	
	13	Relay and 4-20 mA	
	14	Eagle Quantum Premier (EQP)	
	15	Relay and Pulse	
	16	Addressable Module Only (Third Party Type)	
	23	HART, Relay and 4-20 mA	
	TYPE	APPROVAL AGENCY	
	W	FM/CSA/ATEX/CE/IECEX	
	TYPE	CLASSIFICATION*	
	1	Division/Zone Ex d e	
	2	Division/Zone Ex d	

\*Detectors are always Class I, Div. 1.

# APPENDIX A

## FM Approval and Performance Report

THE FOLLOWING ITEMS, FUNCTIONS AND OPTIONS DESCRIBE THE FM APPROVAL:

- Explosion-proof for Class I, Div. 1, Groups B, C and D (T5) Hazardous (Classified) Locations per FM 3615.
- Dust-ignition proof for Class II/III, Div. 1, Groups E, F and G (T5) Hazardous (Classified) Locations per FM 3615.
- Nonincendive for Class I, Div. 2, Groups A, B, C and D (T3) Hazardous (Classified) Locations per FM 3611.
- Nonincendive for Class II, Div. 2, Groups F and G (T3) Hazardous (Classified) Locations per FM 3611.
- Enclosure rating NEMA Type 4X per NEMA 250.
- Ambient Temperature Limits: -40°F to +167°F (-40°C to +75°C).
- Automatic Fire Alarm Signaling Performance verified per FM 3260 (2000).

The following performance criteria were verified:

### OPTICAL INTEGRITY TEST:

The detector generated an optical fault in the presence of contamination on any single or combination of lens surfaces resulting in a loss of approximately 50% of its detection range, verifying that the detector performs a calibrated Automatic Optical Integrity (**oi**) test for each sensor. Upon removal of the contamination, the detector fault was cleared and the detector was verified to detect a fire.

The Manual / Magnetic **oi** performs the same calibrated test as the Automatic **oi**, and additionally actuates the alarm relay to verify output operation. If there is a 50% loss of its detection range, an alarm signal is not generated.

## FM Approvals Description and Performance Report – Continued

### RESPONSE CHARACTERISTICS:

#### Very High Sensitivity

Fuel	Size / Flow Rate	Distance feet (m)	Typical Response Time (seconds)*	TDSA	Quick Fire
n-Heptane	1 x 1 foot	85 (25.9)	15	On	Off
Methane	32 inch plume	60 (18.3)	5	On	Off
Propane	Torch	2 (0.6)	0.04	On	On

#### High Sensitivity

Fuel	Size / Flow Rate	Distance feet (m)	Typical Response Time (seconds)*	TDSA	Quick Fire
n-Heptane	1 x 1 foot	50 (15.2)	8	On	Off
Methane	32 inch plume	35 (10.7)	3	On	Off
Pyrodex	40 grams	10 (3)	0.1	On	On
Black Powder	40 grams	10 (3)	0.04	On	On
n-Heptane	1 x 1 foot	50 (15.2)	6	On	On

#### Low Sensitivity

Fuel	Size / Flow Rate	Distance feet (m)	Typical Response Time (seconds)*	TDSA	Quick Fire
n-Heptane	1 x 1 foot	15 (4.6)	8	On	Off

### RESPONSE CHARACTERISTICS IN THE PRESENCE OF FALSE ALARM SOURCES:

#### High Sensitivity, TDSA On, Quick Fire Off

False Alarm Source	Distance feet (m)	Fire Source	Distance feet (m)	Typical Response Time (seconds)*
Sunlight, direct, modulated/unmodulated	—	2 inch dia Heptane	10 (3)	< 30
Sunlight, reflected, modulated/unmodulated	—	2 inch dia Heptane	10 (3)	< 30
70 w sodium vapor lamp, unmodulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	3
70 w sodium vapor lamp, modulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	3
250 w mercury vapor lamp, unmodulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	2
250 w mercury vapor lamp, modulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	3
300 w incandescent lamp, unmodulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	3
300 w incandescent lamp, modulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	3
500 w shielded quartz halogen lamp, unmodulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	2
500 w shielded quartz halogen lamp, modulated	5 (1.5)	2 inch dia Heptane	5 (1.5)	2
1500 w electric radiant heater, unmodulated	10 (3)	2 inch dia Heptane	5 (1.5)	3
1500 w electric radiant heater, modulated	10 (3)	2 inch dia Heptane	3 (0.9)	13
Two 34 w fluorescent lamps, unmodulated	3 (0.9)	2 inch dia Heptane	10 (3)	3
Two 34 w fluorescent lamps, modulated	3 (0.9)	2 inch dia Heptane	10 (3)	5
Arc welding	15 (4.6)	2 inch dia Heptane	5 (1.5)	N/A

\*Add 2 seconds for EQP Model.



## FM Approvals Description and Performance Report – Continued

### FALSE ALARM IMMUNITY:

#### High Sensitivity, TDSA On, Quick Fire Off

False Alarm Source	Distance feet (m)	Modulated Response	Unmodulated Response
Sunlight, direct, reflected	—	No alarm	No alarm
Vibration	NA	No alarm	No alarm
Arc welding	15 (4.6)	No alarm	No alarm
70 w sodium vapor lamp	3 (0.9)	No alarm	No alarm
250 w mercury vapor lamp	3 (0.9)	No alarm	No alarm
300 w incandescent lamp	3 (0.9)	No alarm	No alarm
500 w shielded quartz halogen lamp	3 (0.9)	No alarm	No alarm
1500 w electric radiant heater	10 (3)	No alarm	No alarm
Two 34 w fluorescent lamps	3 (0.9)	No alarm	No alarm

### FIELD OF VIEW:

#### Very High Sensitivity, Quick Fire Off

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Typical Horiz. Response Time (seconds)*	Vertical (degrees)	Typical Vert. Response Time (seconds)*
n-Heptane	1 x 1 foot	42.5 (13)	+45	12	+45	10
			-45	14	-30	16
Methane	32 inch plume	30 (9.1)	+45	7	+45	6
			-45	4	-30	4

#### High Sensitivity, TDSA On, Quick Fire Off

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Typical Horiz. Response Time (seconds)*	Vertical (degrees)	Typical Vert. Response Time (seconds)*
n-Heptane	1 x 1 foot	25 (7.6)	+45	7	+45	6
			-45	7	-30	5
Methane	32 inch plume	17.5 (5.3)	+45	6	+45	4
			-45	3	-30	4

#### High Sensitivity, TDSA On, Quick Fire On

Fuel	Size	Distance feet (m)	Horizontal (degrees)	Typical Horiz. Response Time (seconds)*	Vertical (degrees)	Typical Vert. Response Time (seconds)*
Black Powder	40 Grams	5 (1.5)	+45	0.04	+45	0.04
			-45	0.03	-30	0.04

\*Add 2 seconds for EQP Model.

## **APPENDIX B**

### **CSA Certification**

#### **PRODUCTS**

**CLASS 4818 04** - SIGNAL APPLIANCES - Systems - For Hazardous Locations

Class I, Division 1, Groups B, C, and D (T5); Class II, Division 1, Groups E, F, and G (T5);  
Class I, Division 2, Groups A, B, C, and D (T3); Class II, Division 2, Groups F and G (T3);  
Class III; Enclosure Type 4X;

Infrared Flame Detector/Controller X9800 series, rated 18-30 Vdc, 2.1 Watts to 16.5 Watts.  
Relay contacts rated 5 Amps @ 30 Vdc.

# APPENDIX C

## ATEX Approval

### EC-TYPE EXAMINATION CERTIFICATE

#### DEMKO 02 ATEX 132195X

##### Increased Safety Model

CE 0539 Ex II 2 G

Ex d e IIC T5–T6 Gb

T6 (T<sub>amb</sub> –50°C to +60°C)

T5 (T<sub>amb</sub> –50°C to +75°C)

IP66.

##### Flameproof Model

CE 0539 Ex II 2 G

Ex d IIC T5–T6 Gb

T6 (T<sub>amb</sub> –55°C to +60°C)

T5 (T<sub>amb</sub> –55°C to +75°C)

IP66.

#### Compliance with:

EN 60079-0: 2009

EN 60079-1: 2007

EN 60079-7: 2007

EN / IEC 60529: 2001.

### INSTALLATION INSTRUCTIONS

The field wiring connections in the terminal compartment are ATEX certified and accepts wiring diameter from 14 AWG (2.08 mm<sup>2</sup>) to 22 AWG (0.33 mm<sup>2</sup>).

The flame detector model X9800IR shall be installed according to the instructions given by the manufacturer.

The cable entry devices shall be certified in type of explosion protection flameproof enclosure "d" for use with the terminal compartment in type of explosion protection flameproof enclosure "d", or in type of explosion protection increased safety "e" for use with the terminal compartment in type of explosion protection increased safety "e". They shall be IP66 rated, suitable for the conditions of use and correctly installed.

Unused entries shall be closed with suitable certified blanking elements.

The metal housing for the Infrared (IR) flame detector type X9800 must be electrically connected to earth ground.

For ambient temperatures below –10°C and above +60°C use field wiring suitable for both minimum and maximum ambient temperature.

#### Special conditions for safe use:

The EOL resistor can only be used within the flameproof terminal compartment.

EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

The Infrared (IR) flame detector type X9800 is to be installed in places where there is a low risk of mechanical damage.

# APPENDIX D

## IECEx Approval

### IECEx CERTIFICATE OF CONFORMITY

#### DEMKO

IECEx ULD 06.0018X

Ex d e IIC T5-T6 Gb		Ex d IIC T4-T6 Gb
T6 ( $T_{amb} = -50^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ )	or	T6 ( $T_{amb} = -55^{\circ}\text{C}$ to $+60^{\circ}\text{C}$ )
T5 ( $T_{amb} = -50^{\circ}\text{C}$ to $+75^{\circ}\text{C}$ )		T5 ( $T_{amb} = -55^{\circ}\text{C}$ to $+75^{\circ}\text{C}$ )
IP66.		IP66.

#### Compliance with:

IEC 60079-0: 2007  
IEC 60079-1: 2007  
IEC 60079-7: 2006  
EN / IEC 60529: 2001.

### INSTALLATION INSTRUCTIONS

The field wiring connections in the terminal compartment are suitably certified and accepts wiring diameter from 14 AWG (2.08 mm<sup>2</sup>) to 22 AWG (0.33 mm<sup>2</sup>).

The flame detector model X9800IR shall be installed according to the instructions given by the manufacturer.

The cable entry devices shall be certified in type of explosion protection flameproof enclosure "d" for use with the terminal compartment in type of explosion protection flameproof enclosure "d", or in type of explosion protection increased safety "e" for use with the terminal compartment in type of explosion protection increased safety "e". They shall be IP66 rated, suitable for the conditions of use and correctly installed.

Unused entries shall be closed with suitable certified blanking elements.

The metal housing for the Infrared (IR) flame detector type X9800 must be electrically connected to earth ground.

For ambient temperatures below  $-10^{\circ}\text{C}$  and above  $+60^{\circ}\text{C}$  use field wiring suitable for both minimum and maximum ambient temperature.

#### Special conditions for safe use:

The EOL resistor can only be used within the flameproof terminal compartment.

EOL resistors must be ceramic, wirewound type, rated 5 watts minimum, with actual power dissipation not to exceed 2.5 watts.

The Infrared (IR) flame detector type X9800 is to be installed in places where there is a low risk of mechanical damage.

## **APPENDIX E**

### **VdS Schadenverhütung GmbH Approval**

#### **VdS**

Performance per EN54-10,  
Certificate of Approval G-203084.

EC-Certificate of Conformity  
08 0786 – CPD – 20779  
EN54-10 Flame detectors - Point detectors.

#### **SUBJECT MATTER OF THE APPROVAL**

IR Flame Detector Type X9800 for use in Automatic Fire Detection and Fire Alarm Systems.

#### **BASIS OF APPROVAL**

DIN EN 54, Part 10 (05/02) - Flame Detectors.

#### **INSTRUCTIONS FOR THE APPLICATION OF THE APPROVAL COMPONENT/SYSTEM**

The Installation shall take into account, that the orientation arrow on the flame detector is directed upwards, as the view angle in this direction is <90°.

The IR-flame detector corresponds to class 1.



95-8554



X3301 Multispectrum  
IR Flame Detector



PointWatch Eclipse®  
IR Combustible Gas Detector



FlexVu® Universal Display  
w/ GT3000 Toxic Gas Detector



Eagle Quantum Premier®  
Safety System

Your local German **DET-TRONICS** Distributor:

d.s.f. GmbH  
Spessartstr. 11  
D - 63263 Neu - Isenburg  
Phone: +49 (0)6102 / 7890 - 0  
Telefax: +49 (0)6102 / 7890 - 40  
E-Mail: [info@dsf-gmbh.de](mailto:info@dsf-gmbh.de)



A UTC Fire & Security Company

Det-Tronics, the DET-TRONICS logo, Protect•IR, and Automatic Optical Integrity (o<sub>2</sub>) are registered trademarks or trademarks of Detector Electronics Corporation in the United States, other countries, or both. Other company, product, or service names may be trademarks or service marks of others.

© Copyright Detector Electronics Corporation 2010. All rights reserved